

## BATTERY CHECKER LAYOUT

Buttons

1. Battery Type: NiCd/NiMH, Li-Po, LiFe, Li-Ion
2. Cell Number: NiCd/NiMH(4~7 Cells), Lithium type(2~7 Cells)
3. Display Mode: Battery cell voltages, total voltages, Lowest cell voltage, Highest cell voltage, Voltage gap between highest cell voltage and lowest cell voltage, Remaining battery capacity(%)




← NiCd/NiMH Type Battery Input

← Lithium Battery Input  
(Using balancing connector)

### NiCd/NiMH TYPE BATTERY

? Battery total voltage numbers.


? Set cell




Total voltages, and remaining capacity(%)

n.b. The capacity shown for Nixx type cells is not accurate and should not be relied upon.


NiCd and NiMH batteries for the TX and RX (4~7 cells) can be connected to this capacity checker.



### LITHIUM TYPE BATTERIES



? JST EH and JST XH type plugs on lithium battery packs can be directly connected to this battery checker.



When using with Thunder Power/Flight Power and Polyquest type batteries, it is necessary to use an adaptor board with balance adaptor board lead.

FS-BLEAD Balance Adaptor Board Lead

FS-BAPQ Balance Adaptor Board Polyquest

FS-BATP Balance Adaptor Board Flight Power/Thunder Power

### NEW Balance Function:

Long press the first key, LIPO/LIFE/LIIO will blink, says it is in balance, balance process

according to the second button can view each battery voltage, balance is take the battery in the

lowest section as the benchmark to discharge balance